



OWB FLOODLIGHT INSTRUCTIONS



1: The OWB Floodlight comes with three slide adjustment hardware kits. Prior to installing the kit, place your unloaded gun with light attached into the holster and snug the retention screws.



2: Match the spacer size to the sight channel gap, as close as you can.

3: Install all three posts and washers, then install the screws.



4: Place the unloaded gun in the holster and then snug the screws equally until the retention is perfect.

Do not mix and match the hardware kits!



5. The three hardware kits provide four ranges of adjustment. The Green kit, the smallest, can be installed with the rubber washer between the holster and the screw post, for guns with narrow slides, in addition to being installed conventionally, with the washer between the holster halves.

